

Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly completed to avoid accidentally discarding parts.
- Take out all parts and hardware from box.

Parts List

Item	Description	DRAWING	QTY
P1	Legs		4
P2	Chair		1

Hardware List


Item	Description	DRAWING	QTY
H1	Plastic Washer		4

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGE RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assemble Procedures:

Step 1. Assemble the chair on a flat, soft surface such as carpet or cloth to prevent scratches. Take out the legs (P1) and plastic washers (H1).



Step 2. Screw in the legs (P1) using Plastic Washer (H1) for each. Screw tight to the right of the chair frame.



Step 3. Level the chair and place the chair upright on a level surface. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL USE. THIS ITEM SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. PLEASE ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase

STRUCTIONS

y accent chair

carding small parts or hardware.

DAMAGES

ng the finish. Take out Legs and plastic

angle.



Remove the plastic
caps from screw
heads before
attaching legs.

e.

YDAY USE. THEY SHOULD BE
Y.ALWAYS CHECK TO ENSURE