

ASSEMBLY INSTRUCTIONS

Description : TACOMA DINING CHAIR

Important safety instructions:

- Please read all instructions carefully before assembly
- For your safety and ease, assembly by two or more adults is recommended
- Keep instructions for future use

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware
- Take out all parts and hardware from the box

Part List




NO.	DESCRIPTION	IMAGE	QTY
P1	Backrest		1
P2	Seat		1
P3	Side Frame R / L		2
P4	Long Metal Support		1
P5	Short Metal Support		1

Hardware List

NO.	DESCRIPTION	IMAGE	QTY
H1	Bolt (6x40mm)		8
H2	Bolt (6x20mm)		2
H3	Allen Key		1

DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. THE SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEMS BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Step 1

Step 2

Step 3


Assembly Completed

ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.

THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase