

ASSEMBLY INSTRUCTIONS

Description: Dining Chair





Important safety instructions:

- Please carefully read all instructions before assembling the chair.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Seat Cushion 	1
B	Chair Back 	1
C	Back Legs 	1
D	Side Stretchers 	2

Hardware List

Item	Description	QTY
a	Bolts Ø5/16*2" 	6
b	Lock Washers 5/16" 	6
c	Flat Washers 5/16" *19mm 	6
d	Allen Wrench 5/16" 	1
e	Screws #8*1-1/2" 	4



Assembly Procedures:


Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach seat cushion (A) to chair back (B) as shown below. Securely tighten the bolts with Allen wrench (d).

(a)x3 Bolts Ø5/16*2" 


(b)x3 Lock Washers 5/16" 

(c)x3 Flat Washers 5/16" *19mm 

(d)x1 Allen Wrench 5/16" 



Step 2. Insert two side stretchers (D) to the holes on the legs of chair back (B), then attach the back legs (C) to the end of stretchers (D) as shown below.



Step 3. Loosely assemble the back legs (C) on the bottom of seat cushion (A) as shown below. Securely tighten the bolts with Allen wrench (d).

(a)x3 Bolts Ø5/16*2"




(b)x3 Lock Washers 5/16"



(c)x3 Flat Washers 5/16" *19mm




(d)x1 Allen Wrench 5/16"




Step 4. Tighten the screws (e) through the stretchers (D) to the legs with screw driver(not provided).

(e)x4 Screws #8*1-1/2" 



Step 5. Make sure the assembled chair is level and securely tighten all the bolts with Allen wrench (d). Turn the assembled chair to an upright position. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase