

ASSEMBLY INSTRUCTIONS

Description: Armless Lounge

Important safety instructions:

- Please carefully read all instructions before assembling the lounge.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
P1	Seat	1
P2	Back Leg Frame	1
P3	Back Top Rail	1
P4	Front Feet	2

Hardware List

Item	Description	QTY
H1	Short Bolts Ø1/4" *3/4"	3
H2	Lock Washers 1/4"	3
H3	Flat washers 1/4"	3
H4	Small Allen Wrench 1/4"	1
H5	Long Bolts Ø5/16" *1-1/2"	4
H6	Lock Washers 5/16"	4
H7	Flat washers 5/16"	4
H8	Big Allen Wrench 5/16"	1
H9	Long Screw #8*1-3/4"	3
H10	"U" Metal Bracket	1
H11	Short Screw #8 *5/8"	1




Note: These hardware are for setting up a unit, please see the "Assembly instructions for Setting up a unit"

Assembly Procedures:

Step 1. Assemble the lounge on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach back top rail (P3) to the back leg frame (P2) as shown below. Loosely tighten the bolts with Allen wrench (H4).

- (H1)x2 Short Bolts Ø1/4" *3/4"
- (H2)x2 Lock Washers 1/4"
- (H3)x2 Flat washers 1/4"
- (H4)x1 Big Allen Wrench 1/4"



Step 2.


- 1) Loosely attach the back leg frame (P2) to the seat (P1) as shown below.
- 2) Attach front legs (P4) to the bottom of seat (P1) as shown below.

(H5)x4 Long Bolts Ø5/16" *1-1/2" 

(H6)x4 Lock Washers 5/16" 

(H7)x4 Flat washers 5/16" 


(H8)x1 Big Allen Wrench 5/16" 



Step 3.

- 1) Make sure the back leg frame (P2) center on the back of seat (P1), then securely tighten the bolts.
- 2) Securely tighten the screws (H9) with screw driver(not provided). Assembly is complete. Make sure the lounge is lever and securely tighten all bolts with Allen wrench (H8).
- 3) To level lounge. After completing all other steps, stand the lounge upright on all four legs. If there is a gap between a leg and the floor. Please adjust the adjustable leveler up or down under each leg.
- 4) **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H9)x3 Long Screw #8*1-3/4" 



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase