

DESCRIPTION: Accent Chair

Important safety instructions:

Please carefully read all instructions before assembling.

For your safety and ease, assembly by two or more adults is recommended.

Keep instructions for future use.

Pre-assembly:

Remove all parts and hardware from box along with any plastic protective packaging.

Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware




Parts List

Item	Description	QTY
P1	Front Legs	2
P2	Back Legs	2
P3	Chair	1
P4	Seat Cushion	1


Hardware List

Item	Description	QTY
H1	Bolts φ5/16" * 2-3/16"	4
H2	Lock Washers φ5/16"	4
H3	Flat Washers φ5/16"	4
H4	Allen Wrench φ5/16"	1
H5	Plastic Wahser	2


Step 1: Take out the legs and hardwares under the seat cushion.



Step 2: Turn the chair upside down and lay on protective carpet, using flat washers (H3), lock washers (H2), bolts (H1), connect legs (P2) to chair (P3). Tighten bolts (H1) with Allen Wrench (H4). Screw in the front legs (P1) into the screw holes underneath the base by using plastic washers P2



Step 3: Place chair upright on a level surface. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase