



ASSEMBLY INSTRUCTIONS

Preston Accent Chair


Important safety instructions:

- Please read carefully all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly completed to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box .

Parts List

Item	Description	DRAWING	QTY
P1	Backrest		1
P2	Chair Seat		1
P3	Front Leg		2
P4	Back Leg		2

Hardware List


Item	Description	DRAWING	QTY
H1	Plastic Washer		4

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assemble Procedures:


Step 1. Assemble the chair on a flat, soft surface such as carpet or cloth to prevent scratching the finish. Open the carton and take out legs inner b




Step 2. Screw in the front legs (P3) using Plastic Washer (H1) for each. Screw tight to the right angle.




Step 3. Screw in the front legs (P4) using Plastic Washer (H1) for each. Screw tight to the right angle.



Step 4. Insert the small metal arms on the sides of the Chair Backrest(P1) into the prefabricated slide lock gadget on the Chair Seat(P2) as shown above.



Step 5. Level the chair and place the chair upright on a level surface. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.