

ASSEMBLY INSTRUCTIONS

Description: Roxie accent chair





Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1		Back Cushion	1PC
P2		Seat Cushion	1PC
P3		Left leg	1PC
P4		Right leg	1PC

Hardware List

Item	Description		QTY
H1	M6*30MM		8PCS
H2	M6*40MM		4PCS
H3	(Ø6+Ø10)*2MM		8PCS
H4	(Ø6+Ø16)*1MM		8PCS
H5	M6		1PC


DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


Assembly Procedures:

Step 1. We recommend assembly on a table or counter top.


Turn the seat cushion(P2) upside down and put on the legs(P3&P4), 80% tighten bolts(H1) and washer(H3&H4) with allen wrench(H5) as illustration below.



Step 2. Put the chair on a level surface. Connect the back cushion(P1), 80%tighten bolts (H2) with allen(H5) as illustration below.



Step 3. Adjust levelers (as drawing) as necessary. Fully tighten the bolts as illustration below.



ADDITIONAL NOTE ABOUT SAFETY:
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.
THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY,
AND ENSURE STABILITY.

Thank you for your purchase