

ASSEMBLY INSTRUCTIONS

DESCRIPTION: Colwell Accent Chair

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description	QTY
P1	Chair Seat	1
P2	Chair Back	1
P3	Right Frame Leg	1
P4	Left Frame Leg	1
P5	Back Stretcher	1
P6	Seat Cushion	1
P7	Back Cushion	1

Hardware List

Item	Description	QTY
H1	Bolts Ø1/4"x 2 3/8" L	4
H2	Bolts Ø1/4"x 1 1/2" L	11
H3	Lock Washers Ø1/4"	15
H4	Flat Washers Ø1/4" x Ø14mm	4
H5	Flat Washers Ø1/4" x Ø16mm	11
H6	Allen Wrench	1
H7	Wood Plug	4

DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Open the back fabric of chair back & black fabric of bottom. Attach the Chair Seat (P1) to the Chair Back (P2) as shown below. Then tighten all the bolts and close back fabric.

(H2)x7 Bolts Ø1/4"x 1 1/2" L

(H3)x7 Lock Washers Ø1/4" Ø

(H5)x7 Flat Washers Ø1/4" Ø

* Note: Put the chair back (P2) to the chair seat (P1) with concentric insert holes.



Step 2: Attach the Chair Seat (P1) & Back Stretcher (P5) to the Right Frame Leg (P3) & the Left Frame Leg (P4) as shown below. Then close the bottom fabric.


(H1)x4 Bolts Ø1/4" x 2 3/8" L

(H2)x4 Bolts Ø1/4" x 1 1/2" L

(H3)x8 Lock Washers Ø1/4"

(H4)x4 Flat Washers Ø1/4"

(H5)x4 Flat Washers Ø1/4"




Step 3:


a. Turn the chair to an upright position.

b. Attach Wood Plug (H7) to the Right Frame Leg (P3) & the Left Frame Leg (P4) as shown below.

(H7)x4 Wood Plug



Step 4: Attach the Seat Cushion (P6) & Back Cushion (P7) to the chair as shown below. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase