

Description: Dining Bench

Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Table top	1
B	Legs	4
C	Center Legs	2



Hardware List

Item	Description	QTY
a	Bolts Ø5/16*2"	12
b	Lock Washers 5/16"	12
c	Flat Washers 5/16"(22mm)	12
d	Allen Wrench 5/16"	1


Assembly Procedures:

Step. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.

- 1) Attach the each leg (B & C) to the table top (A) as shown below . Securely tighten the bolts with Allen wrench (d) .
- 2) Turn the assembled table to an upright position. Assembly is complete.

(a)x12 Bolts (b)x12 Lock Washers (c)x12 Flat Washers (d)x1 Allen Wrench

Note: The center legs can be adjusted with adjustable levelers.



Caution: Failure to follow these instructions may cause the bolts to misalign during assembly.

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase