

# ASSEMBLY INSTRUCTIONS

## Description: Ezra Loveseat





### Important safety instructions:


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

### Pre-assembly:




- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

### Parts List

Item	Description		QTY
P1	Back Cushion		1
P2	Seat Cushion		1
P3	Right Leg Frame	 (P3)	1
P4	Left Leg Frame	 (P4)	1




### Hardware List

Item	Description		QTY
H1	Bolts Ø5/16*2-1/2"		12
H2	Lock Washers Ø5/16"		12
H3	Flat Washers Ø5/16" *19mm		12
H4	Allen Wrench 5/16"		1

### Assembly Procedures:




Step 1. Assemble the loveseat on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Open the bottom covering of seat cushion (P2). Then loosely attach seat cushion (P2) to back cushion (P1) as shown below.


- |        |              |   |
|--------|--------------|---|
| (H1)x4 | Bolts        |  |
| (H2)x4 | Lock Washers |  |
| (H3)x4 | Flat Washers |  |
| (H4)x1 | Allen Wrench |  |



Step 2.


- 1) Attach right leg frame (P3) to back cushion (P1) and seat cushion (P2) as shown below.
- 2) Attach left leg frame (P4) to back cushion (P1) and seat cushion (P2) as shown below.
- 3) Securely tighten all bolts with Allen wrench (H4).

- (H1)x8 Bolts 
- (H2)x8 Lock Washers 
- (H3)x8 Flat Washers 



Step 3.

- 1) Turn the assembled lounge to an upright position. Make sure the lounge is level and securely tighten all the bolts and with Allen wrench (H4).
- 2) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchase