

Description: Corner sofa**Important safety instructions:**


- Please carefully read all instructions before assembling the sofa.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
1.	Seat	
2.	Back Frames	
3.	Back Cushion	
4.	Pillow	
5.	Front Leg	

**Hardware List**

Item	Description	QTY	
a	Bolts Ø5/16"x2"		4
b	Bolts Ø5/16"x1-1/2"		8
c	Spring Washers 5/16"		12
d	Flat Washers 5/16*3/4"		12
e	Allen Wrench 5/16"		1
f	Nut 3/8"		1
g	Lock Washers Ø3/8"		1
h	Flat Washers Ø3/8" *22mm		1
i	Open Wrench 3/8"		1

Assembly Procedures:

Step 1. Assemble the sofa on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach seat (1) to back frame (2) as shown below. Securely tighten the bolts with Allen wrench (e).

(b)x8 Bolts Ø5/16"x1-1/2"




(c)x8 Spring Washers 5/16"



(d)x8 Flat Washers 5/16*3/4"



(e)x1 Allen Wrench 5/16"



Step 2. Attach the leg (5) to the seat (1) as shown below. Securely tighten the bolts with open wrench (i)

(f)x1 Nut 3/8"




(g)x1 Lock Washers Ø3/8"



(h)x1 Flat Washers Ø3/8" *22mm




(i)x1 Open Wrench 3/8"



Step 3.


- 1) Turn the assembled lounge to an upright position.
- 2) Attach back cushion (3) to back frames (2) as shown below. Securely tighten the bolts with Allen wrench (e).

(a)x4 Bolts Ø5/16"x2"
(c)x4 Spring Washers 5/16"
(d)x4 Flat Washers 5/16*3/4"
(e)x1 Allen Wrench 5/16"



Step 4.

- 1) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.
- 2) Put the pillow (4) on the assembled sofa.






Step 5. Set up a unit

1) Place the assembled lounge and assembled corner sofa at your desired position. The bottoms have locks as shown below.


2) Option unit

Turn the assembled sofas and lounge to a upright position, then lock the locks on bottom of lounge and corner sofas.




Step 6. Please take off the outside locks which is not used after assembled is complete as shown below.

Caution: Taking off the locks with Screw driver (not provide) before you turn the lounge and sofa to an upright position.



Step 7.

- 1) Turn the assembled lounge and corner sofas to a upright position
- 2) To level sofa. After completing all other steps, stand the lounge upright on all four legs. If there is a gap between a leg and the floor. Please adjust the adjustable leveler up or down under each leg.



All bottom of
legs have
adjustable
leveler

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase