

ASSEMBLY INSTRUCTIONS

Description: Accent Table


Important safety instructions:


- Please carefully read all instructions before assembling the chair.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Legs	
B	Center Post	
C	Top Panel	



Hardware List

Item	Description	QTY
a	Short Bolts Ø1/4*1/2"	
b	Long Bolts Ø1/4*3/4"	
c	Lock Washers Ø1/4"	
d	Big Flat Washers Ø1/4" *19mm	
e	Allen Wrench 1/4"	
f	Metal Bar	

Assembly Procedures:

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach each leg (A) to the center post (B). Securely tighten all bolts with Allen wrench (e) .

(a)x6 Short Bolts




(c)x6 Lock Washers



(d)x6 Big Flat Washers



(e)x1 Allen Wrench



Step 2. Attach the assembled Legs (A) and center post (B) to the top panel (C). Securely tighten all bolts with Allen wrench (e).


(b)x4 Long Bolts



(c)x4 Lock Washers




(d)x4 Big Flat Washers



Step 3.

- 1) Turn the assembled table to an upright position. Securely tighten all the bolts with Allen wrench (e).
- 2) Attach tighten the bolt on on the center post (B) using metal bar (f) through the hole on the bolt head. To adjust the table top height, loose the bolts on center post (B) with metal bar (f), then turn the table top to desired location, and then tighten the bolts.
- 3) Assembly is complete.

(f)x1 Metal Bar



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase