

INK+IVY ZEN END TABLE

Assembly instructions:


PARTS LIST

| No. | DESCRIPTION | IMAGE | QTY |
|-----|--------------|-------|-----|
| P1 | TOP AND BASE | | 2 |
| P2 | LEGS FRAME | | 2 |


HARDWARE LIST

| No. | DESCRIPTION | IMAGE | QTY |
|-----|-----------------|-------|-----|
| H1 | BOLT Ø1/4"x50mm | | 8 |
| H2 | SPRING WASHER | | 8 |
| H3 | FLAT WASHER | | 8 |
| H4 | ALLEN KEY | | 1 |
| H5 | WOODEN DOWEL | | 8 |


1 PLACE WOODEN DOWELS INTO P1 HOLES




2



3



4



Adjust leveler for balance

ASSEMBLY COMPLETED

NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy assembly should be performed by people.