










SONOMA END TABLE

Assembly instructions:

PARTS LIST

No.	DESCRIPTION	IMAGE	Q'TY
P1	TABLE TOP		1
P2	LEGS FRAME		2
P3	METAL STRECHER		1

HARDWARE LIST

No.	DESCRIPTION	IMAGE	Q'TY
H1	BOLT (Ø5/16" X 35 MM)		4
H2	BOLT (Ø1/4" X 25 MM)		1
H3	BOLT (Ø1/4" X 40 MM)		2
H4	SPRING WASHER (Ø5/16")		4
H5	FLAT WASHER (Ø5/16")		4
H6	SPRING WASHER (Ø1/4")		3
H7	FLAT WASHER (Ø1/4")		3
H8	WOOD PLUG		2
H9	ALLEN KEY		1

NOTE: PO # is located underneath/ at the back side of each item.
Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy. Assembly should be performed by two people.

Adjust leveler for stable

ASSEMBLY COMPLETE

