



OAKTOWN END TABLE

Assembly instructions:

| PARTS LIST | | | |
|------------|-------------|-------|------|
| No. | DESCRIPTION | IMAGE | Q'TY |
| P1 | BODY | | 1 |
| P2 | LEG FRAME | | 2 |
| P3 | SHELF | | 1 |

| HARDWARE LIST | | | |
|---------------|-----------------------|-------|------|
| No. | DESCRIPTION | IMAGE | Q'TY |
| H1 | BOLT (Ø1/4" x 40 MM) | | 10 |
| H2 | SPRING WASHER (Ø1/4") | | 10 |
| H3 | FLAT WASHER (Ø1/4") | | 10 |
| H4 | ALLEN KEY | | 1 |

NOTE: PO # is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy. Assembly should be performed by two people.

1

* DON'T TIGHTEN BOLTS UNTIL FINAL STEP

2

3

4

ASSEMBLY COMPLETED