

ASSEMBLY INSTRUCTIONS

Description: Kelly End Table




Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
P1	Table Top		1
P2	Shelf		1
P3	Legs		4





Hardware List


Item	Description		QTY
H1	Long Bolts		4
H2	Short Bolts		8
H3	Lock Washers		12
H4	Flat washers		12
H5	Metal Bracket		4
H6	Allen Wrench		1



Assembly Procedures:


Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach three legs (P3) to table top (P1) as shown below.

- (H1)x3 Long Bolts 
- (H3)x3 Lock Washers 
- (H4)x3 Flat washers 
- (H6)x1 Allen Wrench 



Step 2. Loosely attach the shelf (P2) to the assembled three legs (P3) using metal bracket (H5) as shown below. Loosely tighten the bolts with Allen wrench (H6).


- (H2)x6 Short Bolts
- (H3)x6 Lock Washers
- (H4)x6 Flat washers
- (H5)x4 Metal Bracket
- (H6)x1 Allen Wrench



Step 3.

- a) Loosely attach the fourth leg (P3) to the assembled table top (P1) and shelf (P2) as shown below.
- b) Securely tighten all bolts with Allen wrench (H6). Turn the assembled table to an upright position.
- c) Assembly is complete.
- d) **Failure to follow these instructions may cause the bolts to misalign during assembly.**

- (H1)x4 Long Bolts
- (H2)x2 Short Bolts
- (H3)x2 Lock Washers
- (H4)x2 Flat washers
- (H5)x1 Metal Bracket
- (H6)x1 Allen Wrench



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.