

ASSEMBLY INSTRUCTIONS

Description: Dining & Counter Table

Important safety instructions:

- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Table Top	1
B	Leg Frame -1	1
C	Leg Frame -2	1




Hardware List


Item	Description	QTY
a	Short Bolts $\varnothing 1/4"$ * $3/4"$ L	4
b	Long Bolts $\varnothing 1/4"$ * 2" L	1
c	Lock Washers $\varnothing 1/4"$	4
d	Flat Washers $\varnothing 1/4"$	4
e	Plastic Washer $\varnothing 1/4"$ * 20mm	1
f	Allen wrench 1/4"	1



Assembly Procedures:


Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach the leg frame-1 (C) to the leg frame-2 (B) as shown below. Securely tighten the bolts with Allen wrench (f).

- (b)x1 Long Bolts 
- (e)x1 Plastic Washer 
- (f)x1 Allen wrench 




Step 2. Loosely attach the assembled legs (C, B) to the bottom of table top (A) as shown below.

- (a)x4 **Short Bolts** 
- (c)x4 **Lock Washers** 
- (d)x4 **Flat Washers** 



Step 3.

- 1) Securely tighten all bolts with Allen wrench (f). Turn the assembled counter table to an upright position.
- 2) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for you purchase