

Description: Dining Table

Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Table Tops	2
B	Metal Supports	2
C	Leg Frames	2
D	Stretcher	1




Hardware List

Item	Description	QTY
a	Short Bolts Ø1/4"x3/4"	30
b	Medium Bolts Ø1/4"x1-1/4"	2
c	Long Bolts Ø1/4"x1-1/2"	2
d	Lock Washers 1/4"	34
e	Flat Washers 1/4"	34
f	Allen Wrench 1/4"	1

Assembly Procedures:

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach metal supports (B) to the table tops (A) as shown below. Securely tighten all bolts with Allen wrench (f).

(a)x12	Short Bolts	
(b)x2	Medium Bolts	
(d)x14	Lock Washers	
(e)x14	Flat Washers	
(f)x1	Allen Wrench	



Step 2. Loosely attach the leg frames (C) to the assembled table tops (A) as shown below. Securely tighten all bolts with Allen wrench (f).


(a)x16 Short Bolts



(d)x16 Lock Washers



(e)x16 Flat Washers



Step 3.

1) Loosely attach stretcher (D) to the leg frames (C) and the table tops (A) as shown below.

2) Securely tighten all bolts with Allen wrench (f). Turn the assembled table to an upright position.

3) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.

(a)x2 Bolts




(c)x2 Bolts



(d)x4 Lock Washers



(e)x4 Flat Washers



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase