









PARTS LIST

No	DESCRIPTION	IMAGE	QTY
P1	TOP		1
P2	LEG FRAME		4
P3	LEG FRAME		1

HARDWARE LIST


No	DESCRIPTION	IMAGE	QTY
H1	BOLT Ø1/4"x20mm		2
H2	BOLT Ø1/4"x35mm		8
H3	SPRING WASHER Ø1/4"		4
H4	FLAT WASHER Ø1/4x16"		4
H5	ALLEN KEY		1



NOTE: PO# is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy. Assembly should be performed by two people.

DISCLAIMER: When properly assembled, this item is safe for intended use. Seller is not liable for any damages resulting from item being improperly assembled after purchase.

ADDITIONAL NOTE ABOUT SAFETY:
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.
THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

1


2**3****ASSEMBLED COMPLETE**