

Description: Dining Table

Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Table tops	2
B	Support Rails	2
C	Legs	4



Hardware List


Item	Description	QTY
a	Bolts Ø5/16*2-1/2"	20
b	Lock Washers 5/16"	20
c	Flat Washers 5/16"(22mm)	20
d	Allen Wrench 5/16"	1

Assembly Procedures:

Step 1. Turn the table top (A) upside down on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.

1) Remove the cleats from the bottom of table tops (A) by unscrewing the screws with screwdriver(not provide) on the cleat at the bottom of table top .

2) Turn on the locks on bottom of table tops (A).



Step 2. Attach the support rails (B) to the bottom of table tops (B) as shown below. Securely tighten all bolts by Allen wrench (d).

(a)x12 Bolts Ø5/16*2-1/2"




(b)x12 Lock Washers 5/16"



(c)x12 Flat Washers 5/16"(22mm)



(d)x12 Allen Wrench 5/16"



Step 3.

1) Loosely attach each leg (C) to the assembled top as shown below. Securely tighten all bolts with Allen wrench (d).

2) Turn the assembled table to an upright position. Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.


(a)x8 Bolts Ø5/16*2-1/2"



(b)x8 Lock Washers 5/16"



(c)x8 Flat Washers 5/16"(22mm)



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase