

**Important safety instructions:**

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

**Parts List**

| Item | Description | QTY |
|------|-------------|-----|
| P1   | Cabinet Top | 1   |
| P2   | Legs        | 4   |

**Hardware List**

| Item | Description        | QTY |
|------|--------------------|-----|
| H1   | Bolts Ø1/4" x 60mm | 8   |
| H2   | Lock Washers Ø1/4" | 8   |
| H3   | Flat Washers Ø1/4" | 8   |
| H4   | Allen Wrench       | 1   |

**DISCLAIMER:**

**WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.**

**Assembly Procedures:**

Step 1: Assemble the Nightstand on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach Legs (P2) to Top Cabinet Top (P1) as shown below. Securely tighten all bolts with Allen Wrench (H4).

(H1)x8 Bolts Ø1/4" x 60mm




(H2)x8 Lock Washers Ø1/4"



(H3)x8 Flat Washers Ø1/4"




(H4)x1 Allen Wrench



Step 2: Turn the assembled Nightstand to an upright position.

Assembly is complete.



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchasing