

# OAKTOWN DRESSER

Assembly instructions:

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	FRAME		1
P2	LEG		2


HARDWARE LIST

No.	DESCRIPTION	IMAGE	QTY
H1	LONG BOLT (6 x 35MM)		8
H2	SHORT BOLT (6 x 18MM)		2
H3	SMALL FLAT WASHER (Ø14MM)		8
H4	BIG FLAT WASHER (Ø18MM)		2
H5	SPRING WASHER		10
H6	ALLEN KEY		1
H7	METAL PLATE		1
H8	ANTI TIP KIT		1 SET


NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.  
CAUTION: Item is heavy assembly should be performed by two people.

OPTION 1


1



2



3




ASSEMBLY COMPLETED

OAKTOWN DRESSER


Assembly instructions:

OPTION 2


1




2



3




4



Anti Tip Kit hardware has been attached to the product. P1s, install to the wall to prevent product from tipping.

5



Adjustable leveler

ASSEMBLY COMPLETED