











# RENU DRESSER

Assembly instructions:

## PARTS LIST

No	DESCRIPTION	IMAGE	QTY
P1	BODY		1
P2	LEG		4


## HARDWARE LIST

No	DESCRIPTION	IMAGE	QTY
H1	BOLT (Ø1/4" x 20 MM)		10
H2	FLAT WASHER (Ø1/4"x13)		8
H3	SPRING WASHER (Ø1/4"x13)		10
H4	FLAT WASHER (Ø1/4"x19)		2
H5	ALLEN KEY (4x60mm)		1
H6	ANTI TIP KIT		1 SET
H7	METAL PLATE (76x18x2mm)		1
H8	PHILIP SCREW		NOT PROVIDE

NOTE: PO # is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary.


CAUTION: Item is heavy. Assembly should be performed by two people.

## 1 OPTION 1



## 2

Anti Tip Kit hardware has been attached to the product. Pls. install to the wall to prevent product from tipping



ASSEMBLED COMPLETE

## Warning:

Serious or fatal injuries can occur from furniture tip-over. To help prevent furniture tip-over: Use provided mounting hardware to secure furniture to the wall. This may educe but not eliminate the risk of furniture tip-over. Do not allow children to climb on furniture. Keep remote controls, toys, and other items that might attract children off of this product. Unless specifically designed to accommodate, do not set televisions or other heavy objects on top of this product.