









Avery Dining Chair

Assembly Instruction:

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	Seat		1
P2	Leg		4
P3	Seat Cushion		1

HARDWARE LIST


No.	DESCRIPTION	IMAGE	QTY
H1	Bolts		12
H2	Washers		12
H3	Allen Wrench		1

NOTE:PO# is located underneath/inside of each item. Please be prepare to provide this # should any claim be necessary.


CAUTION: Item is heavy assembly should be performed by two people.

Estimate assembly time: 5 minutes

Step 1. Turn the seat (P1) over and attach the legs (P2) to the bottom frame by using bolts (H1), and washers (H2), securely tighten all bolts with Allen Wrench (H3).



Step 2. Upright the chair on a level surface, then place the seat cushion (P3) on the seat .



ASSEMBLY
COMPLETED