



Avery Boat Dining Table

Assembly Instruction:

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	Table Top		1
P2	Table leg		4

HARDWARE LIST


No.	DESCRIPTION	IMAGE	QTY
H1	Bolts		16
H2	Washers		16
H3	Allen Wrench		1

NOTE: PO# is located underneath/inside of each item. Please be prepared to provide this # should any claim be necessary.


CAUTION: Item is heavy assembly should be performed by two people.

Estimate assembly time: 5 minutes

Step 1. Turn the table top (P1) over and attach the legs (P2) to the table bottom frame by using bolts (H1) and washers (H2), securely tighten all bolts with Allen Wrench (H3).



Step 2. Level the table and upright on a level surface.



ASSEMBLY COMPLETED