

ASSEMBLY INSTRUCTIONS

Description: Mercer 24" Pedestal

Important safety instructions:


- Please carefully read all instructions before assembling the pedestal.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
A	Top Panel		1
B	Metal Base		1

**Hardware List**

Item	Description		QTY
a	Bolts Ø1/4" x 3/4"		4
b	Spring Washers Ø1/4"		4
c	Flat Washers Ø1/4"		4
d	Allen Wrench 4mm		1
e	Clear Plastic Pads		4

Assembly Procedures:

1. Turn the pedestal top upside down on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.
- 1) Attach the metal base (B) to the top panel (A) using bolts (a), spring washers (b) and flat washers (c) as shown below. Securely tighten all bolts by Allen wrench (d), but do not over tighten.
- 2) place the clear plastic pad (e) on the bottom of base (B) as shown below.
- 3) Turn the assembled pedestal to an upright position. Assembly is complete.

