

## ASSEMBLY INSTRUCTIONS

## Description: Side Table

## Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

## Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

## Parts List

Item	Description	QTY
A	Top Frame	1
B	Shelf Frames	2
C	Legs	4
D	Side Bottom Rails	2
E	Long Top Glass	1
F	Short Shelf Glasses	2




## Hardware List


Item	Description	QTY
a	Long Bolts Ø1/4"x1-1/4"	12
b	Short Bolts Ø1/4"x7/8"	8
c	Lock Washers 1/4"	20
d	Small Flat Washers 1/4"*12mm	12
e	Allen Wrench 1/4"	1
f	Wood Plugs	8
g	Big Flat Washers 1/4"*16mm	8

## Assembly Procedures:

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the legs (C) to the shelf frames (B) using long bolts (a), lock washers (c) and flat washers (d) , then attach the side bottom rails (D) to the bottom of legs (C) using long bolts (a), lock washers (c) and flat washers (d). Securely tighten all the bolts with Allen wrench (e).




Step 2. Turn the table top frame upside down on a flat, soft surface such as a carpet or cloth. Attach the the top frame (A) to the assembled base through the metal plate on the top of side legs (C) using short bolts (b), lock washers (c) and flat washers (g). Securely tighten all the bolts with Allen wrench (e).



Step 3.

- 1) Turn the assembled table to an upright position. Securely tighten all bolts with Allen wrench (e), but do not over tighten the bolts.
- 2) Attach wooden plugs (f) to each exposed bolt hole, tighten with rubber hammer to knock the wooden plug till its tighten. Note: use a soft cloth between the wooden plug and hammer to prevent damage to wooden plug finish
- 3) Gently lay the long top glass (E) and short shelf glasses (F) on each frame.
- 4) Assembly are complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.