



BENICIA HEADBOARD

Assembly instructions:

1


PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	L - HB PANEL		1
P2	R - HB PANEL		1
P3	L - LEG		1
P4	R - LEG		1
P5	WALL HANGER BAR		1

HARDWARE LIST

No.	DESCRIPTION	IMAGE	QTY
H1	BOLT		9
H2	FLAT WASHER		9
H3	SPRING WASHER		9
H4	ALLEN KEY		1
H5	SCREW		Not provide
H6	SCREW DRIVER		Not provide

NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.
CAUTION: Item is heavy assembly should be performed by two people.



BENICIA HEADBOARD

Assembly instructions:

OPTION 1	OPTION 2
<div> <div>2</div> </div>	<div> <div>2</div> <p>Consult with your local hardware store on the best method to attach the hanger bar to your wall. Drywall anchors should be used on sheet rock walls, masonry screws on brick walls, wood screws can be used if attached directly into wood studs.</p> </div>
<div> <div>3</div> </div>	<div> <div>3</div> <div>4</div> </div>

ASSEMBLY COMPLETED

ASSEMBLY COMPLETED