

ASSEMBLY INSTRUCTIONS

Description: Cirque End Table





Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.



Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
P1	Top Box		1
P2	Shelf		1
P3	Leg 1	 (P3)	2
P4	Leg 2	 (P4)	2

Hardware List

Item	Description		QTY
H1	Bolts M10 *10mmL		12
H2	Open Wrench		1





Assembly Procedures:

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach three legs (P1 & P2) to the box (P1) following the labels "P3 & P4" on the legs and the corner of top box accordingly.


(H1)x6 Bolts

(H2)x1 Open Wrench



Step 2. Loosely attach the shelf (P2) to the assembled three legs (P2 & P3) using bolts (H1) as shown below.


(H1)x3 Bolts 



Step 3.

- 1) Loosely attach the last leg (P4) to assembled top box (P1) and shelf (P2) using bolts (H1) as shown below.
- 2) Make sure the table is level and securely tighten all bolts with open wrench (H2). Turn the assembled table to an upright position.
- 3) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H1)x3 Bolts 



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase