

ASSEMBLY INSTRUCTIONS

Description: Dining Chair






Important safety instructions:


- Please carefully read all instructions before assembling the chair.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:







- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
A	Chair Back		1
B	Seat Cushion		1
C	Legs		2
D	Front stretcher (413mm long)		1
E	Side stretchers (443mm long)		2



Hardware List

Item	Description		QTY
a	Bolts Ø5/16"*3"		8
b	Bolts Ø5/16"*1-1/2"		2
c	Lock Washers 5/16"		10
d	Flat Washers 5/16"		10
e	Allen Wrench 5/16"		1
f	Wood Screws 8#*1-1/2"		6