


ASSEMBLY INSTRUCTION


Dining Chair

Parts#	Parts Name	Drawing	Qty
A	Wood front legs		2
B	Back with back legs		1
C	Allen wrench		1
D	Washer		9
E	Bolt		9
F	Spring washer		9
G	Seat		1

Step 1. Turn the chair upside down and lay on protective carpet , Open the black fabric of the bottom, and take out the legs (A) underneath the seat (G)



Step 2: Attach the chair legs to seat frame, insert the bolts (E) and spring washer(F) and washers (D). then tighten the bolts with allen wrench (C)



Step 3: Turn the chair over

