

**Important safety instructions:**

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

**Parts List**


Item	Description		QTY
P1	Front legs		2
P2	Back legs		2
P3	Chair top		1

**Hardware List**

Item	Description		QTY
H1	Bolts Dia.8 x 30mm		12
H2	Lock Washers Dia.8		12
H3	Flat Washers Dia.8		12
H4	Allen Wrench		1


**Assembly Procedures:**

Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.  
Remove the legs and hardware package from the chair.




Step 2: Attach front legs (P1) and back legs (P2) to chair top (P3) following a label number (P1, P2) on each leg accordingly and using Lock washers (H2), Flat washers (H3) and Bolt (H1) as shown below.

(H1)x12 Bolts Dia.8 x 30mm   
(H2)x12 Lock Washers Dia.8   
(H3)x12 Flat Washers Dia.8   
(H4)x1 Allen Wrench 



Step 3: Turn the assembled chair to an upright position. Assembly is complete.



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchase