

ASSEMBLY INSTRUCTIONS**Description: Reyi Accent Chair****Important safety instructions:**


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
P1	Chair Top		1
P2	Front Legs		2
P3	Right Back Leg	 (P3)	1
P4	Left Back Leg	 (P4)	1

**Hardware List**

Item	Description		QTY
H1	Bolts Ø5/16**2-1/2"		8
H2	Lock Washers 5/16"		8
H3	Flat Washers 5/16"		8
H4	Allen Wrench 5/16"		1

Assembly Procedures:

Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.


- 1) Loosely attach the front/back legs (P2, P3) to the chair top (P1) following the labels "P3" P4" on the left/right back leg accordingly and using bolts (H1), lock washers (H2), flat washers (H3) as shown below.
- 2) Turn the assembled chair to an upright position. Make sure the chair is level and securely tighten all bolts with Allen wrench (H4). Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H1)x8 Bolts

(H2)x8 Lock Washers

(H3)x8 Flat Washers

(H4)x1 Allen Wrench



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase