

Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is completed to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any protective packaging.


Parts List

Item	Description	DRAWING	QTY
P1	FRONT LEGS (Label: LEFT)		1
P2	FRONT LEGS (Label: RIGHT)		1
P3	BACK LEGS		2
P4	CHAIR		1


Hardware List

Item	Description	DRAWING	QTY
H1	PLASTIC WASHER		4


Step 1. Assemble the chair on a flat, soft surface such as carpet or cloth to prevent scratching. Take out all the legs and hardware on the seat.



Step 2. Then turn the chair seat upside down. Place washers(H1) on legs(P1,P2,P3) and attach to chair seat by screwing clockwise into corresponding holes.



Step 3. Place chair upright on a level surface. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase