

**Important safety instructions:**


- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

**Parts List**

Item	Description		QTY
P1	Chair Top		1
P2	Front Legs	 	2
P3	Back Legs	 	2

**Hardware List**

Item	Description	QTY
H1	Bolts Ø1/4"**3/4"	8
H2	Lock Washers Ø1/4"	8
H3	Flat Washers Ø1/4"**19mm	8
H4	Allen Wrench 1/4"	1

**Assembly Procedures:**

Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the front legs (P2) and back legs (P3) to the chair top (P1) as shown below.

(H1)x8 Bolts Ø1/4"\*\*3/4"




(H2)x8 Lock Washers Ø1/4"




(H3)x8 Flat Washers Ø1/4"\*\*19mm



(H4)x1 Allen Wrench 1/4"



Step 2. Securely tighten all bolts, turn the assembled chair to an upright position. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchase