

**Important safety instructions:**


- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

**Parts List**

Item	Description		QTY
P1	Chair Top		1
P2	Front Legs	 	2
P3	Back Legs	 	2


**Hardware List**

Item	Description	QTY
H1	Bolts Ø1/4"**3/4"	16
H2	Lock Washers Ø1/4"	16
H3	Flat Washers Ø1/4"**19mm	16
H4	Allen Wrench 1/4"	1


**Assembly Procedures:**

Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the front legs (P2) and back legs (P3) to the chair top (P1) as shown below.

(H1)x16 Bolts Ø1/4"\*\*3/4"  
 (H2)x16 Lock Washers Ø1/4"  
 (H3)x16 Flat Washers Ø1/4"\*\*19mm  
 (H4)x1 Allen Wrench 1/4"



Step 2. Securely tighten all bolts, turn the assembled chair to an upright position. Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase