

MADISONPARK®

ASSEMBLY INSTRUCTIONS

Description: Emma Accent Chair




Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.





Pre-assembly:


- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Chair Top		1
P2	Metal Legs		4
P3	Pillow		1

Hardware List


Item	Description		QTY
H1	Bolts Ø5/16"*1"		16
H2	Lock Washers Ø5/16"		16
H3	Flat Washers Ø5/16"		16
H4	Allen Wrench 5/16"		1




Assembly Procedures:

Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the metal legs (P2) to chair top (P1) as shown below.

- (H1)x16 Bolts Ø5/16"*1"
- (H2)x16 Lock Washers Ø5/16"
- (H3)x16 Flat Washers Ø5/16"
- (H4)x1 Allen Wrench 5/16"



Step 2. Securely tighten all bolts, turn the assembled chair to an upright position, then put the pillow (P3) on the chair back as shown below. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



Note: The legs can be adjusted with adjustable levelers.

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase