

**Important safety instructions:**


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

**Parts List**

Item	Description	QTY
P1	Top	1
P2	Leg	4


**Hardware List**

Item	Description	QTY
H1	Bolt Ø5/16"**2-3/4"L	8
H2	Lock Washer 5/16"	8
H3	Flat washer 5/16"	8
H4	Allen Wrench 5/16"	1

**Assembly Procedures:**


Step 1. Turn over the top (P1) on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach legs (P2) to the bottom of top (P1) as shown below image 1.

(H1)x8 Bolt Ø5/16"\*\*2-3/4"L

(H2)x8 Lock Washers 5/16"

(H3)x8 Flat washers 5/16"

(H4)x1 Allen Wrench 5/16"



Step 2.

- 1) Securely tighten all bolts. then turn the assembled ottoman to an upright position. Make sure the assembled ottoman is level.
- 2) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

**Thank you for your purchase**