

Important safety instructions:


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
P1	Top	1
P2	Base	1



Hardware List

Item	Description	QTY
H1	Bolts Ø1/4" * 2-1/8"L	4
H2	Lock Washers Ø1/4"	4
H3	Flat Washers Ø1/4"	4
H4	Allen Wrench 4mm	1

Assembly Procedures:

Step 1. Assemble the product on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.

- 1) Loosely attach base (P2) to the bottom of top (P1) using bolts (H1), lock washers (H2) and flat washers (H3) as shown below.
- 2) Turn the assembled product to an upright position. Make sure the product is level and securely tighten all bolts with Allen wrench (H4).
- 3) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase