

# ASSEMBLY INSTRUCTIONS

## Rickard Accent Bench





### Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






### Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any protective packaging.

### Parts List

Item	Description		QTY
P1	Seat Cushion		1
P2	Side Frame		2
P3	Front and Back Frame		2
P4	Stretcher		5

### Hardware List

Item	Description		QTY
H1	Short Bolts Ø1/4"×1/2"		28
H2	Long Bolts Ø1/4"×1-1/2"		4
H3	Lock Washers 1/4"		4
H4	Flat Washers 1/4"		4
H5	Allen Wrench 1/4"		1


### Assembly Procedures:

Step 1. Assemble the bench on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.  
Insert the front and back frame (P3) to the stretcher (P4) as shown below image 1.

(H1)x20 Short Bolts Ø1/4"×1/2" 

(H5)x1 Allen Wrench 1/4" 

Image 1



Step 2. Insert the side frame (P2) to the assembled front and back frame (P3) as shown below image 2.

(H1)x8 Short Bolts Ø1/4\*\*1/2" 

(H5)x1 Allen Wrench 1/4" 




Image 2

Step 2. Attach the assembled frame to the bottom of seat cushion (P1) as shown below image 3, securely tighten all bolts with Allen wrench (H5), make sure the bench is leveled and aligned properly. Turn the assembled bench to an upright position. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**


(H2)x4 Long Bolts Ø1/4\*\*1-1/2" 

(H3)x4 Lock Washers 1/4" 

(H4)x4 Flat washers 1/4" 

(H5)x1 Allen Wrench 1/4" 

Image 3



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

**Thank you for your purchase**