

MADISON PARK

ASSEMBLY INSTRUCTIONS

Description: Lisa Dining Chair

Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
P1	Chair Back	1
P2	Seat Cushion	1
P3	Front Legs	2

Hardware List


Item	Description	QTY
H1	Short Bolts Ø5/16"**2-1/2"	6
H2	Long Bolts Ø5/16"**3-1/2"	4
H3	Lock Washers 5/16"	10
H4	Flat Washers 5/16"	10
H5	Allen Wrench 5/16"	1



Assembly Procedures:

Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach seat cushion (P2) to the chair back (P1). Securely tighten all bolts with Allen wrench (H6) .

- (H1)x2 Short Bolts Ø5/16"**2-1/2"
- (H2)x4 Long Bolts Ø5/16"**3-1/2"
- (H3)x6 Lock Washers Ø5/16
- (H4)x6 Flat Washers Ø5/16
- (H5)x1 Allen Wrench Ø5/16




Step 2. Attach front legs (P3) to seat cushion (P2) as shown below. Securely tighten all bolts with Allen wrench (H5) .

(H1)x4 Short Bolts Ø5/16" *2-1/2" 

(H3)x4 Lock Washers Ø5/16 


(H4)x4 Flat Washers Ø5/16 

(H5)x1 Allen Wrench Ø5/16 



Step 3. Turn the assembled chair to an upright position. Assembly is complete.

Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase