





Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







Pre-assembly:


- Do not discard any content until assembly completed to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Chair Back		1
P2	Front Legs		2
P3	Seat Cushion		1
P4	Fabric Cover		1


Hardware List

Item	Description		QTY
H1	Long Bolts Ø5/16"x3-1/4"L		4
H2	Medium Bolts Ø5/16"x2-1/4"L		4
H3	Short Bolts Ø5/16"x1-3/4"L		1
H4	Lock Washers 5/16"		9
H5	Flat Washers 5/16" *19mm		9
H6	Allen Wrench 5/16"		1

**Assembly Procedures:**

Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the seat cushion (P3) to the chair back (P1) as shown below image 1.

- (H1)x4 Long Bolts Ø5/16"x3-1/4"L 
- (H3)x1 Short Bolts Ø5/16"x1-3/4"L 
- (H4)x5 Lock Washers 5/16" 
- (H5)x5 Flat Washers 5/16" 
- (H6)x1 Allen Wrench 5/16" 



Step 2. Attach the front legs (P2) to the seat cushion (P3) as shown below image 2.




- (H2)x4 Medium Bolts $\varnothing 5/16$ "x2-1/4"L 
- (H4)x4 Lock Washers 5/16" 
- (H5)x4 Flat Washers 5/16" 
- (H6)x1 Allen Wrench 5/16" 

Image 2



Step 3.

- 1) Securely tighten all bolts with Allen wrench (H6).
- 2) Turn the assembled chair to an upright position, make sure the chair is level. Open the zipper then put the fabric cover (P4) to the assembled chair, assembly is complete.
- 3) **Failure to follow these instructions may cause the bolts to misalign during assembly.**



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase