

MADISON PARK

ASSEMBLY INSTRUCTIONS

Description: Pratt End Table



Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
1.	Top Frame		1
2.	Bottom Panel		1
3.	Side Frames		2
4.	Connecting Posts		4
5.	Glass		1




Hardware List

Item	Description		QTY
a	Bolts Ø1/4"x1"		12
b	Bolts Ø1/4"x5/8"		2
c	lock Washers 1/4"		2
d	Flat Washers 1/4"		2
e	Allen Wrench 1/4"		1
f	Clear Plastic Pad		4

Assembly Procedures:


Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach each connecting (4) to the top frame (1) as shown below. Do not tighten for making adjustment at Step 2 at this time.



Step 2.


- 1) Insert connecting post (4) to side frame (3) as shown below.
- 2) Then using bolts (a) to tighten with Allen wrench (e).

(a)x4 Bolts Ø1/4"x1"
(e)x1 Allen Wrench 1/4"




Step 3. Attach the bottom panel (2) to assembled the side frames (3) as shown below.

(a)x8 Bolts Ø1/4"x1"
(b)x2 Bolts Ø1/4"x5/8"
(c)x2 lock Washers 1/4"
(d)x2 Flat Washers 1/4"




Note: The legs can be adjusted with adjustable levelers.



Step 4.

- 1) Make sure the table is level and securely tighten all bolts with Allen wrench (e). Turn the assembled table to an upright position.
- 2) Place the clear plastic pad (f) on the table top as shown below.
- 3) Gently lay the glass (5) on the table top.
- 4) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase