

Important safety instructions:

- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
P1	Table Top	1
P2	Leg Frames	2
P3	Stretchers	2

Hardware List

Item	Description	QTY
H1	Bolts Ø1/4"x1/2" L	12
H2	Bolts Ø1/4"x1-1/2" L	4
H3	Lock Washers Ø1/4"	16
H4	Flat Washers Ø1/4"	16
H5	Allen Wrench 1/4"	1
H6	Brackets	2
H7	Screw #8 * 1-1/4"	4

**Assembly Procedures:**

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach one leg frame (P2) to the bottom of table top (P1) using bolts (H2), lock washers (H3) and flat washers (H4) as shown below.

(H2)x2 Bolts Ø1/4"x1-1/2" L




(H3)x2 Lock Washers Ø1/4"




(H4)x2 Flat Washers Ø1/4"



(H5)x1 Allen Wrench 1/4"



Step 2. Attach each stretcher (P3) to leg frames (P2), do not tighten the bolts at this time.



Step 3.

- 1) Fix the stretchers (P3) and the leg frames (P2) using bolts (H1&H2), lock washers (H3) and flat washers (H4) as shown below.
- 2) Loosely attach the brackets (H6) to the back of table using bolts (H1), lock washers (H3) and flat washers (H4)
- 3) Tighten all screws (H7) though the top rail of the leg frames (P2) to the bottom of table top (P1) with screw driver (not provided).
- 4) Turn the assembled table to an upright position.
- 5) Make sure the table is level and securely tighten all bolts with Allen wrench (H5).
- 6) **Leveler adjustment:** Leveler are pre-installed on the legs and adjust as needed to make sure the table is level. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H1)x12 Bolts Ø1/4"x1/2" L



(H2)x2 Bolts Ø1/4"x1-1/2" L



(H3)x14 Lock Washers Ø1/4"



(H4)x14 Flat Washers Ø1/4"





(H6)x2 Brackets




(H7)x4 Screw #8 * 1-1/4"



Screw driver (not provided)



Adjustable Leveler on the bottom of legs.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase