





ASSEMBLY INSTRUCTIONS**Description: Maison End Table****Important safety instructions:**

- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List


Item	Description		QTY
P1	Top Panel		1
P2	Top Stretcher		1
P3	Bottom Stretcher		1
P4	Legs		4

Hardware List

Item	Description		QTY
H1	Short Bolts Ø1/4" *5/8"L		16
H2	Long Bolts Ø1/4" *3-1/2"L		4
H3	Lock Washers		20
H4	Flat Washers		20
H5	Allen Wrench		1

**Assembly Procedures:**

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Insert each inserted bar on each leg (P4) to the end of top stretcher (P2) and the end of bottom stretcher (P3), do not tighten the bolts at this time.



Step 2. Loosely attach each leg (P4) to top stretcher (P2) and bottom stretcher (P3) using short Bolts (H1), lock washers (H3) and flat washers (H4) as shown below.

(H1)x16 Short Bolts $\varnothing 1/4"$ *5/8"L





(H3)x16 Lock Washers



(H4)x16 Flat Washers



(H5)x1 Allen Wrench



Step 3.

- 1) Loosely attach assembled metal base to the bottom of top panel (P1) using long Bolts (H2), lock washers (H3) and flat washers (H4) as shown below.
- 2) Securely tighten all short bolts (H1) with Allen wrench (H5), then securely tighten all long bolts (H2) with Allen wrench (H5).
- 3) Turn the assembled table to an upright position.
- 4) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



(H2)x4 Long Bolts $\varnothing 1/4"$ *3-1/2"L



(H3)x4 Lock Washers



(H4)x4 Flat Washers



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase