

Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List


Item	Description	QTY
P1	Top Panel	1
P2	Self Panel	1
P3	Right Frame	1
P4	Left Frame	1
P5	Back Frame	1

**Hardware List**

Item	Description	QTY
H1	Short Bolts $\varnothing 1/4" *5/8" L$	8
H2	Long Bolts $\varnothing 1/4" *1-1/2" L$	8
H3	Lock Washers	16
H4	Flat Washers	16
H5	Allen Wrench	1

Assembly Procedures:

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Insert each inserted bar on back frame (P5) to the end of left/right frame (P3,P4) following the labels "P3" "P4" on the left frame (P3), right frame (P4) and back frame (P5) accordingly as shown below, do not tighten the bolts at this time.



Step 2. Loosely attach left/right frame (P3,P4) to back frame (P5) using short Bolts (H1), lock washers (H3) and flat washers (H4) as shown below.

(H1)x8 Short Bolts Ø1/4" *5/8" L




(H3)x8 Lock Washers



(H4)x8 Flat Washers



(H5)x1 Allen Wrench



Step 3.

- 1) Loosely attach assembled metal base to the bottom of top panel (P1) using long Bolts (H2), lock washers (H3) and flat washers (H4) as shown below.
- 2) Securely tighten all bolts with Allen wrench (H5). Attach the shelf panel (P2) to the assembled metal base using long Bolts (H2), lock washers (H3) and flat washers (H4).
- 3) Securely tighten all bolts with Allen wrench (H5). Turn the assembled table to an upright position.
- 4) **Leveler adjustment:** Leveler are installed on the frames and adjust as needed to make sure the table is level. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H2)x8 Long Bolts Ø1/4" *1-1/2" L




(H3)x8 Lock Washers



(H4)x8 Flat Washers



Adjustable
Leveler on the
bottom of
frames.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase