

Important safety instructions:


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
P1	Table Top Frame	1
P2	Shelf	1
P3	Glass Top	1
P4	Leg	2


**Hardware List**

Item	Description	QTY
H1	Bolt Ø1/4"**1"	12
H2	Allen Wrench 1/4"	1
H3	Clear Plastic Pad	4

Assembly Procedures:


Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the table top frame (P1) to the leg (P4) as shown below. Loosely tighten the bolts with Allen wrench (H2).

(H1)x3 Bolt Ø1/4"**1" 
 (H2)x1 Allen Wrench 1/4" 




Step 2. Attach shelf (P2) to the leg (P4) as shown below. Loosely tighten the bolts with Allen wrench (H2).

(H1)x3 Bolt Ø1/4" *1"
(H2)x1 Allen Wrench 1/4"



Step 3. Attach another leg (P4) to the assembled table top (P1) and shelf (P2) as shown below. Securely tighten the bolts with Allen wrench (H2).


(H1)x6 Bolt Ø1/4" *1"
(H2)x1 Allen Wrench 1/4"



Step 4.

- 1) Securely tighten all bolts with Allen wrench (H2). Turn the assembled table to an upright position
- 2) To level table. If there is a gap between a leg and the floor, please adjust the adjustable leveler up or down under each leg.
- 3) Put the clear plastic pad (H3) on the table top frame (P1) as shown below, then gently lay the glass top (P3) on the clear plastic pad (H3).
- 4) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H3)x4 Clear Plastic Pad



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase