






Important safety instructions:


- Please carefully read all instructions before assembling the table.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List


Item	Description		QTY
P1	Top Frame		1
P2	Shelf Frame		1
P3	Wood Legs		4
P4	Metal Legs		4
P5	Glass		1

**Hardware List**

Item	Description		QTY
H1	Long Bolt $\phi 1/4'' \times 1-1/2''$ L		4
H2	Medium Bolt $\phi 1/4'' \times 3/4''$ L		4
H3	Short Bolt $\phi 1/4'' \times 1/2''$ L		4
H4	Lock Washer 1/4"		8
H5	Flat Washer 1/4"		8
H6	Allen Wrench 1/4"		1

Assembly Procedures:


Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach wood legs (P3) to the shelf frame (P2) as shown below.

(H1)x4 Long Bolts $\phi 1/4'' \times 1-1/2''$ L 

(H4)x4 Lock Washer 1/4" 

(H5)x4 Flat Washer 1/4" 

(H6)x1 Allen Wrench 1/4" 




Step 2. **Loosely** attach the metal leg (P4) to the wood legs (P3) as shown below.

(H2)x4 Medium Bolts $\phi 1/4 \times 3/4$ " L

(H4)x4 Lock Washers 1/4"

(H5)x4 Flat Washers 1/4"


(H6)x1 Allen Wrench 1/4"



Step 3. Attach the top frame (P1) to the assembled metal legs (P4) as shown below.


(H3)x4 Short Bolts $\phi 1/4 \times 1/2$ " L

(H6)x1 Allen Wrench 1/4"



Step 4.

- Securely tighten all bolts with Allen wrench (H2). Gently lay the glass (P5) on the top frame (P1).
- Assembly is complete.
- Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase