

# MADISONPARK

## ASSEMBLY INSTRUCTIONS

**Description:** Lisa Dining Table

### Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

### Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

### Parts List

| Item | Description | QTY |
|------|-------------|-----|
| P1   | Table Top   | 1   |
| P2   | Legs        | 2   |





### Hardware List


| Item | Description           | QTY |
|------|-----------------------|-----|
| H1   | Short Bolts Ø5/16"x1" | 10  |
| H2   | Lock Washers 5/16"    | 10  |
| H3   | Flat Washers 5/16"    | 10  |
| H4   | Allen Wrench 5/16"    | 1   |



### Assembly Procedures:


Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach legs (P2) to the table top (P1). Securely tighten all bolts with Allen wrench (H4).

- (H1)x10 Bolts Ø5/16"x1" 
- (H2)x10 Lock Washers 
- (H3)x10 Flat Washers 
- (H4)x1 Allen Wrench 



Step 2.

- To level Table. After completing all other steps, turn the assembled table to an upright position. If there is a gap between base and the floor, please adjust the adjustable leveler up or down.
- Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchase