

MADISONPARK

ASSEMBLY INSTRUCTIONS

Description: Abbey Dining Table



Important safety instructions:


- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:





- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any protective packaging.

Parts List

Item	Description		QTY
P1	Table Top		1
P2	Legs		4



Hardware List

Item	Description		QTY
H1	Bolt Ø5/16"*2"L		12
H2	Lock Washer 5/16"		12
H3	Flat washer 5/16"		12
H4	Allen Wrench 5/16"		1





Assembly Procedures:


Step 1. Turn over the table top (P1) on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the legs (P2) to the bottom of table top (P1) as shown below image 1.

- (H1)x12 Bolt Ø5/16"*2"L


(H2)x12 Lock Washers 5/16"

(H3)x12 Flat washers 5/16"

(H4)x1 Allen Wrench 5/16"
- 



Step 2. Securely tighten all bolts, then turn the assembled table to an upright position. Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase